

Your Phone

- ① LED bar
- ② Wired microphone ports
- ③ Mute bar
- ④ Softkey buttons
- ⑤ Navigation bar and Select button
- ⑥ Volume key

LED Bar States

The LED bar illuminates to indicate status:

- Green, solid—Active call
- Green, flashing—Incoming call
- Green, pulsing—Held call
- Red, solid—Muted call

Make a Call

Enter a number and press **Call**.

Answer a Call

Press **Answer**.

Put a Call on Hold

1. Press **Hold**.
2. To resume a call from hold, press **Resume**.

View Your Recent Calls

Press **Recents** or press the up navigation key.

View Your Favorites

Press **Favorites** or press the down navigation key to see your speed-dial numbers.



Add Another Person to a Call

1. From an active call, press **Conference**.
2. Enter a number.
3. (Optional) Wait until you hear ringing or until the other person answers the call.
4. Press **Conference**.

Transfer a Call to Another Person

1. From a call that is not on hold, press **Transfer**.
2. Enter the other person's phone number.
3. (Optional) Wait until you hear ringing or until the other person answers the call.
4. Press **Transfer** again.

Mute Your Call

1. Press **Mute**  on the phone or **Mute**  on the extension microphone.
2. Press **Mute** again to turn mute off.

Listen to Voice Messages

Press **Messages** and follow the voice prompts.


Forward All Calls

1. Press **Forward all**.
2. Dial the number that you want to forward to, or press **Message**.
3. When you return, press **Forward off**.

Adjust the Volume in a Call

Press **Volume**  up or down to adjust the volume when the phone is in use.


Adjust the Ringer Volume

Press **Volume**  up or down to adjust the ringer volume when the phone is not in use.


Change the Ringtone

1. Select **Settings > Preferences > Ringtone**.
2. Scroll through the list of ringtones and press **Play** to hear a sample.
3. Press **Set** to save a selection.

Change the Brightness

1. Select **Settings > Preferences > Brightness**.
2. Press the navigation bar  up to increase brightness and down to decrease brightness.
3. Press **Save**.

Pair a Wireless Microphone

1. Select **Settings > Admin Settings > Microphones > Wireless Microphone**.
2. Select either **Microphone 1** or **Microphone 2**, and press **Pair**.
3. Press **Mute**  on the wireless microphone until the microphone LED blinks white.

Unpair a Wireless Microphone

1. Select **Settings > Admin Settings > Microphones > Wireless Microphone**.
2. Select either **Microphone 1** or **Microphone 2**.
3. Press **Unpair** on the base unit.

Charge a Wireless Microphone

1. Place the microphone in the charging cradle.
2. If the LED is not white, remove the microphone and replace it in the cradle.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)